

## Replacement Parts

- 1 400-006 motor
- 2 400-045 PCB 21pin
- 3 400-003 driveshaft
- 4 400-015 underframe
- 5 400-024 bogie tower top
- 6 400-021 driving wheels
- 7 400-017 bogie
- 8 400-029 drive cup
- 9 400-022 bogie frame
- 10 400-025 gear set
- 11 BL1999 coupling
- 12 BL2006 NEM pocket
- 13 400-040 LED board
- 14 500-110 motor bracket
- 15 400-013 buffer beam pack

When ordering parts please quote the catalogue number together with the livery of the model (if appropriate) and number of the part required.

Parts are subject to availability.






Packets of couplers (item 36-030) suitable for this model are available from retailers

### Bachmann Europe Plc

Moat Way  
Barwell  
Leicestershire  
LE9 8EY  
01455 841756  
www.bachmann.co.uk

**The model should be handled carefully as it has many finely detailed parts. It is not suitable for persons under 14 years.**

E3240-IS003



A DCC Sound fitted loco is shown. When fitting a sound decoder to a DC model, fit the speaker box in the cavity shown.