



## Class 47 Diesel Locomotive

### Replacement Parts

- 1 800-006 motor
- 2 800-008 PCB
- 3 800-010 motor bracket
- 4 800-009 driveshaft
- 5 800-013 underframe
- 6 800-013 bogie tower top
- 7 800-032 driving wheels
- 8 800-022 bogie
- 9 BL2007 drive cup
- 10 800-030 bogie frame
- 11 800-020 gear set
- 13 BL1998 coupling
- 14 800-015 LED board
- 15 800-014 buffer beam pack

When ordering parts please quote the catalogue number together with the livery of the model (if appropriate) and number of the part required.

Parts are subject to availability.

Packets of couplers (item 36-030) suitable for this model are available from retailers

